

AC 55

Cummins
Mecc Alte
P 602

ISO8528

GC) &-

SZUTEST

GC - \$\$%

CE

2000/14/EC

&\$\$\$\$%#

ž) \$' ž'\$ž 'D:

	"	kw	"	kw	Amp
400/230	55,00	44,00	50,00	40,00	72,00

fPGDE

GC) &

,) & ž

fDF DŁ

%\$I

ž&(

GC

Standard Specifications

ž


fl ! ž

ž

ž



ALTERNATOR



TRANSFER SWITCH

fPG \$\$\$# \$\$\$

fl ! \$ ž

AC 55

Cummins
Mecc Alte
P 602

Manufacturer		Cummins
Model		S3,8-G6
	% \$# "	
	53,70 kW [71,90HP]	
	L	3,800
	"	97 x 128
		17,5:1
fl # h	"# "	1500
fl "h	L	11,00
	L	14,50
AbsorbedAirDischargeReSourceKey.Text	' # "	3,60
fl '# "h	' # "	82,00
	' # "	4,20
	° C	546,00
		12 V d.c.
	Load	%\$#I
	# "	+)\$I
) \$I
		12,80
		9,50
		6,50

		Mecc Alte
		ECO 32-1L/4
	Hz	50
7 cg	"	50,00
		0,80
		3
	fl t	400/230
Temperature		H

		fl "t		fl "t	
AC 55	870,00	1780,00	950,00	1198,00	105,00
	"	fl "t	"	fl "t	"
AK 30	1140	2470	1010	1461	100

AC 55

Cummins
Mecc Alte
P 602

D * \$ & !



- 1 A U]b'gjh h g[X]gd'Um"
- 2 8]gd'UmgWc``Vi hcb"
- 3 DU[Yf]bZfa UhjcbLVi hcb"
- 4 7ca a cb'U'Ufa 'jbX]Wlhcf"
- 5 Gjh h g@98fj"
- 6 CdYfUhjcb'gYYW]b['Vi hcbg"

8G9ža cXY**\$&\$'5i hc'A U]bg: U]i fY'Wblfc`a cXi 'Y"
6UHfYfmVXUf[Yf']bdi h%, !*(j c'hžci hdi h''&+ž' J) '5 f&(U Ecf% ž U c'h) 5 fV&J ž
9a Yf[YbWlhcd'di g\ Vi hcb'UbX Z gYg'Zf'Wblfc'WfW]rg"

7 ca dcB Ybkg]bghU'YX]b'g\YYhgH'Y'YbWcgj fY'D\cgd\UH'WYa]W'ždfY!WtUhj['cZgH'Y'dfcj]XYg Wffcg]cb
fYg]gjhUbhgi fZUW" Dc'nYgH'f'Wt a dgcjH' dck XYf'hdWtUhZfa g'\][\ ['cgg'UbX'Yl hYa Y'mXi fUVY'Zb]g\ "@cW_UVY
UbX'\]b[YX'dUbY'Xccf'dfcj]XYg'YUgmUWVgg'hc' Wt a dcB Ybhg"

'7 cblfc`dUbY']g a ci bH'Y'cb'VUgYZfUa Y'k]h'gH'Y'gjhUbX" @cWUH'X'UhH'Y'f[\hg]XY'cZH'Y' [YbYfUhcf'gYhfK \Yb'mci
'cc'_UhH'Y'; Yb"GYH'Zca '5 H'fbUhcfL

H'Y'8G9**\$&\$'jg'U'gjhUbXUfX'Wblfc`a cXi 'Y'Zf'ci f[YbYfUhcf'gYhg' i d'hc'&\$\$_J 5 'UbX'ih\Ug'VYYb'XYg][bYX'hc
gjhUhUbX'ghcd'X]YgY'UbX']Ug[YbYfUhcf'gYhg' H'Y'8G9**\$&\$'a cXi 'Y'\Ug'VYYb'XYg][bYX'hc' a cb]hcf[YbYfUhcf
ZYEi YbWzj c'hzWffYbhžYb[]bY'c] dfYggi fYzWtc'UbhHya dYfUh fY'fi bb]b[\ci fg'UbX'VUH'Yfmj c'hg'A cXi 'Y
a cb]hcf'g'Y' a U]bg'gi dd'mUbX'gk]W'c] Yf'hc' h'Y [YbYfUhcf'k \Yb'hc'Y'a U]bg'dck YfZ]g'" H'Y'8G9**\$&\$'U'g
]bX]WUH'Y'g'cdYfUhjcbU'gjh h'UbX'ZU' h'WtBx]hcbg'5i hca UH'W'mg' i h'lb[Xck b'hc'Y'; Yb"GYhUbX[]]b['h'f'Y'Zfghi d
ZU' h'WtBx]hcb'cZ; Yb"GYhZ]i fY'H'Y'@7 8 X]gd'Um]bX]WUH'Y' h'Y'ZU' h'

A]WcdfcWggcf'Wblfc`YX"
@7 8 X]gd'Uma U_Yg]bZfa Uhjcb'YUgmhc'fYUX"
(!)bYZ*(1 % & d]l Y'X]gd'Um'
5i hca UhW'mhUbgZfg VYh'k YYb'a U]bg' fli h'mh'UbX' [YbYfUhcf'dck Yf'
A Ubi U'dfc[fUa a]b[cb'ZfcbhidUbY"
I gYf'Z]YbX'mgYh'i d'UbX'Vi hcb'Umci h'
F Ya ch'gjhH'
9j Ybh'c[]b['f] kg'ck]b['XUH'UbX'ha Y'
7 cblfc'g' Ghcd# YgYh'zA Ubi U'z5i hc'zHYgh'GhUfzVi hcbg"5b'UXX]hcbU'di g\ Vi hcb'bYi h'c' h'Y'@7 8 X]gd'Um]g
i gYX'hc'gWc``h'fc' [\ h'Y'a cXi 'Ygfa YH'f]b['X]gd'Um]

AC 55

Cummins
Mecc Alte
P 602

9B; -B9
 9b[]bY'gdYYX"
 C]`dfYggi fy"
 7cc'UbhH'a dYfUh fy"
 F i b H'a Y"
 6UH'Yfmj c`hg"
 7cbZ] i fUV'Y H'a]b["
 ; 9B 9F 5HCF
 J c`HU[Y ffe@ @Bt'
 7 i ffYbhf@%&@ L'
 : fYeI YbWm
 A 5-BG
 J c`HU[Y ffe@ @Bt'
 : fYeI YbWm
 A Ujbgi fYUXm'
 A Ujbgi YbUV'YX"
 ; Yb"GYhfyUXm'
 ; Yb"GYhYbUV'YX"

K 5F B-B;
 7 \Uf[Y ZU]i fy"
 6UH'Yfm@ck #][\j c`HU[Y
 : U]`h`ghcd"
 @ck #][\ [YbYfUhcfj c`HU[Y
 I bXYf@cj Yf[YbYfUhcf ZYei YbWm
 Cj Yf# bXYf gdYYX"
 @ck c]`dfYggi fy"
 <] \ Wc'UbhH'a dYfUh fy"
 G< I H'8CK BG
 : U]`h`ghcd"
 9a Yf[YbWm@ghcd"
 @ck c]`dfYggi fy"
 <] \ Wc'UbhH'a dYfUh fy"
 Cj Yf# bXYf gdYYX"
 I bXYf@cj Yf[YbYfUhcf ZYei YbWm
 I bXYf@cj Yf[YbYfUhcfj c`HU[Y
 C]`dfYggi fy'gYbgcf cdYb"
 7cc'UbhH'a dYfUh fy'gYbgcf cdYb"
 9@97 HF -7@HF -D
 ; YbYfUhcfj YfW ffYbh

: 'YI JVY gYbgcf WbVY Wtbhfc`YX k]h H'a dYfUh fyž
 dfYggi fyŽdYfWbH[Y fik Ufb]b[#g i Hck b#Y YWf]Wf`f]dL
 @cW" gYH]b[dUfJa YHfg UbX a cb]hcf]b[Zca D7 h
 Wtbhfc`a cXi Y'k]h`1 G6 WbbYW]cb`f]b Ul `* a H


9YW]W]GUZYhm#9A 7 Wta dUH]V]Jm6G 9B `* \$-) \$
 9YW]W]Vi gjbYgg`YeI]da YbH
 6G 9B `* %\$!*& 9A 7 ja a i b]hmgUbXufX"
 6G 9B `* %\$!*(9A 7 Ya]gg]cb gUbXufX

'6UH'YfmWUf[Yf]g'a Ubi ZWm fyX k]h gk]Wm]b[!a cXY'UbX'GA 8 H'VWbc`c[mUbX`h\Ug\][\YZW]YbWm'6UH'YfmWUf[Yf
 a cXY'gfici hdI hJ !=WUfUWfghWgj YfmWcgY`h`gei UfY'UbX`ci hdI h]g) ua dYfZ% ž J Zcf%&j c`hUbX +& Z J Zcf(& J
 #bdI h%, !&* (j c`h5 7 " Dfc]bY & (\$) \Ug`Z`mcI hdI hg\chWfW]hdfchW]cb`UbX`hWbVY i gYX`Ug`UW ffYbhgc`fW"
 Dfc]bY %&\$) #(& (\$) WUf[Yf`Ug\][\YZW]YbWm`cb[Z]Z`ck ZU]i fy fUAYZ][\hk Y][\hUbX`ck`YUhfxU]hYX]b
 UWfXUbW`k]h`]bYUf`UHfbUhj Yg" H`Y WUf[Yf]g ZH`YX k]h`UdfchW]cb`X]cXY`UWcg`h`Y`ci hdI h`7 cbbYWmWUf[Y ZU]
 fY`UmW]`VYH`YYb dcg]hj Y`ci hdI hUbX`7: ci hdI h`H`YmUFY`YeI]ddYX k]h`F: =Z`h`f`f`YXi W`Y`YWfW`bc]gY`fUX]hYX
 Zca`h`Y`XYj]W"; Uj Ub]W`m]gc`UW`X]bdi hUbX`ci hdI h]m]W`m(_`Zcf`][\fy]UV]Jm

AC 55

Cummins
Mecc Alte
P 602

5? " \$!



- 1 Steel structures
- 2 Emergency stop push button
- 3 Control panel is right side of the set.
- 4 Corrosion-resistant locks and hinges
- 5 Base frame -fuel tank.
- 6 Lockable, large doors on each side.
- 7 Lifting Points

ž

ž

ž

ž

ž

ž

&&&&% # "

fl "t	"	1010
fl "t	"	2470
fl "t	"	1461
	L	100